

# **Basics of openCV**

**Sung Soo Hwang** 



- Mat
  - The basic data structure used in openCV
  - Declaration
    - Mat (int rows, int cols, int type)
    - Mat (Size size, int type)
    - Mat (const Mat & m)
    - Mat (Size size, int type, const Scalar& s)



- Pixel type
  - CV\_8U: 8-bit unsigned integer: uchar (0~255)
  - CV\_8S: 8-bit signed integer: schar ( -128~127 )
  - CV\_16U: 16-bit unsigned integer: ushort (0~65535)
  - CV\_16S: 16-bit signed integer: short ( -32768~32767 )
  - CV\_32S: 32-bit signed integer: int (-2147483648~2147483647)
  - CV\_32F: 32-bit floating-point number: float (-FLT\_MAX~FLT\_MAX, INF, NAN )
  - CV\_64F: 64-bit floating-point number: double (-DBL\_MAX~ DBL\_MAX, INF, NAN )
  - Multi-channel array:
     CV\_8UC3, CV\_8U(3), CV\_64FC4, CV\_64FC(4)



#### Example

```
Mat mtx(3, 3, CV_32F);
// make a 3x3 floating-point matrix
Mat cmtx(10, 1, CV_64FC2);
// make a 10x1 2-channel floating-point matrix
(10-element complex vector)
Mat img(1080, 1920, CV_8UC3);
// make a 3-channel (color) image of 1920 columns and 1080 rows.
Mat img(Size(1920, 1080), CV_8UC3);
// make a 3-channel (color) image of 1920 columns and 1080 rows.
```



Example

```
Size:100,150
                                                                       \times
#include "cv.hpp"
#include <iostream>
using namespace cv;
using namespace std;
int main()
          int w = 150, h = 100;
          Mat image(h, w, CV_8UC1, Scalar(255));
          cout << "Size: " << image.size().height << "," << image.size().width << endl;</pre>
          imshow("image", image);
          waitKey(0);
          return 0;
```

C:₩WINDOWS₩system32₩cmd.exe

- For a multi-channel image use Scalar function as
  - Scalar(255,0,0)

# Read an image in openCV



- Read an image
  - Mat imread( const string& filename, int flags=1)
    - Flag value as 1:read image as color image
    - Flag value as 0:read image as gray scale image

```
int main() {
  Mat gray_image, color_image;
  // 0 on the 2nd parameter means read img in grayscale
  gray image = imread("lena.png", 0);
  // blank 2nd parameter means 1, which means read img in colors
  color_image = imread("lena.png");
  imshow("gray image", gray_image);
  imshow("color image", color_image);
  waitKey(0);
  return 0;
```



- Read a video from a file
  - Example 1

```
int main() {
  Mat frame;
  VideoCapture cap;
  // check if file exists. if none program ends
  if (cap.open("background.mp4") == 0) {
    cout << "no such file!" << endl;
    waitKey(0);
  while (1) {
    cap >> frame;
    if (frame.empty()) {
       cout << "end of video" << endl;
       break;
    imshow("video", frame);
    waitKey(33);
```



- Read a video from a webcam
  - Example

```
int main() {
  Mat frame;
  // capture from webcam
  // whose device number=0
  VideoCapture cap(0);
  while (1) {
    cap >> frame;
    imshow("web cam", frame);
    waitKey(16);
```



- Read a video
  - Use VideoCapture Class
  - Methods in VideoCapture Class

	VideoCapture ()
	VideoCapture (const String &filename)
	VideoCapture (const String &filename, int apiPreference)
	VideoCapture (int index)
virtual	~VideoCapture ()
virtual double	get (int propId) const Returns the specified VideoCapture property. More
virtual bool	grab () Grabs the next frame from video file or capturing device. More
virtual bool	isOpened () const Returns true if video capturing has been initialized already. More
virtual bool	open (const String &filename)  Open video file or a capturing device for video capturing. More
virtual bool	open (int index)
virtual bool	open (const String &filename, int apiPreference)
virtual VideoCapture &	operator>> (Mat ℑ)
virtual VideoCapture &	operator>> (UMat ℑ)
virtual bool	read (OutputArray image) Grabs, decodes and returns the next video frame. More
virtual void	release () Closes video file or capturing device. More
virtual bool	retrieve (OutputArray image, int flag=0) Decodes and returns the grabbed video frame. More
virtual bool	set (int propld, double value) Sets a property in the VideoCapture. More



- VideoCapture::get(int propId) propId
  - CAP\_PROP\_POS\_MSEC Current position of the video file in milliseconds or video capture timestamp.
  - CAP\_PROP\_POS\_FRAMES 0-based index of the frame to be decoded/captured next.
  - CAP\_PROP\_POS\_AVI\_RATIO Relative position of the video file: 0 start of the film,
     1 end of the film.
  - CAP\_PROP\_FRAME\_WIDTH Width of the frames in the video stream.
  - CAP\_PROP\_FRAME\_HEIGHT Height of the frames in the video stream.
  - CAP\_PROP\_FPS Frame rate.
  - CAP PROP FOURCC 4-character code of codec.
  - CAP\_PROP\_FRAME\_COUNT Number of frames in the video file.
  - CAP\_PROP\_FORMAT Format of the Mat objects returned by retrieve() .
  - CAP\_PROP\_MODE Backend-specific value indicating the current capture mode.
  - CAP\_PROP\_BRIGHTNESS Brightness of the image (only for cameras).
  - CAP\_PROP\_CONTRAST Contrast of the image (only for cameras).
  - CAP\_PROP\_SATURATION Saturation of the image (only for cameras).
  - CAP\_PROP\_HUE Hue of the image (only for cameras).
  - CAP\_PROP\_GAIN Gain of the image (only for cameras).
  - CAP\_PROP\_EXPOSURE Exposure (only for cameras).
  - CAP\_PROP\_CONVERT\_RGB Boolean flags indicating whether images should be converted to RGB.
  - CAP\_PROP\_WHITE\_BALANCE Currently not supported
  - CAP\_PROP\_RECTIFICATION Rectification flag for stereo cameras (note: only supported by DC1394 v 2.x backend currently)

#### Video Capture example



```
int main() {
  Mat frame;
  VideoCapture cap;
  if (cap.open("background.mp4") == 0) return -1;
  double fps = cap.get(CAP_PROP_FPS);
  double time_in_msec = 0; int curr_frame = 0;
  int total_frames = cap.get(CAP_PROP_FRAME_COUNT);
  // video stops after 3 sec
  while (time in msec < 3000) {
    cap >> frame;
    if (frame.empty()) break;
    time_in_msec = cap.get(CAP_PROP_POS_MSEC);
    curr_frame = cap.get(CAP_PROP_POS_FRAMES);
    // printing current frames over total frames
    cout << "frames: " << curr frame << " / " << total frames << endl;
    imshow("video", frame);
    // calculating the right delay from given fps
    waitKey(1000 / fps);
  waitKey(0);
  return 0;
```

# Display an image/video in openCV



- Display an image
  - Example

```
int main() {
    Mat img;
    img = imread("lena.png", 1);
    imshow("Window", img);
    waitKey(0);
}
```

- Display a video
  - waitKey? int waitKey(int delay=0)
    - Delay in milliseconds.
    - 0 is the special value that means "forever"

```
int main() {
    Mat frame;
    VideoCapture cap("background.mp4");
    while (1) {
        cap >> frame;
        imshow("Window", frame);
        waitKey(30);
    }
}
```